

# LIFELINE™

Low VOC - less than 100 g/L



# ULTRA-7

STIR WELL  
BEFORE AND  
DURING  
USE

## ONE COAT TRANSPARENT WOOD STAIN

rev 7/11

FOR EXTERIOR WALLS AND DECKS

• APPEARANCE • LONGEVITY • VALUE • ENVIRONMENT

VOC compliant in all 50 States

CAUTION - DO NOT TAKE INTERNALLY



**PERMA-CHINK**  
SYSTEMS, INC.



Made in USA

1-800-548-3554

[www.permachink.com](http://www.permachink.com) (approx. 19 liters)

5 gallons

# LIFELINE™ ULTRA - 7

## Directions For Use on Exterior Wood Surfaces

LIFELINE™ ULTRA-7 is a new technology, water-based finish that generates the desired color with the application of a single coat on both horizontal and vertical surfaces.

### STEP #1: INSPECTION

Check for deterioration and decay. Replace or repair deteriorated wood. Contact any Perma-Chink Systems office for information about wood repairs.

### STEP #2: SURFACE PREPARATION

All surfaces should be free from mill glaze and contaminants including dirt, dust, mold and mildew, old finishes, water repellents and wax. Use only materials specifically approved by Perma-Chink Systems Inc. to strip, clean and prepare surfaces. If a borate-based wood preservative has been applied, make sure it is completely dry. **DO NOT APPLY LIFELINE™ ULTRA-7 TO SURFACES THAT HAVE BEEN BRUSHED OR RUBBED WITH STEEL WOOL.** If you do, rust spots may appear under the finish. If the wood has been media blasted or more than a week has passed since the surface of the wood has been cleaned, wash down the surface with a solution of Log Wash™, rinse well and allow the surface to dry before applying LIFELINE ULTRA-7.

**DECKS:** For new, pressure treated decks allow the wood to dry for at least three months before sanding the deck and railings with 60-80 grit sandpaper then clean with Log Wash™. On older decks remove all remnants of existing finishes as well as grey oxidized wood fibers. Contact any Perma-Chink Systems office for information about removing existing finishes and surface preparation products.

### STEP #3: APPLICATION

**COVERAGE RATE:** Approximately 300-400 square feet per gallon over bare wood, depending on surface porosity. **DO NOT THIN or MIX WITH OTHER PRODUCTS. STIR THOROUGHLY BEFORE AND DURING USE.** Wear rubber gloves to avoid stains on skin and fingernails. If multiple containers are used, they should be poured together (boxed) to ensure best color consistency.

**TOOLS:** Airless sprayer with .015 or .017 tip and high quality, synthetic bristle brush. For decks, a paint pad makes application easy. **DO NOT USE ROLLERS.**

**TECHNIQUE:** LIFELINE™ ULTRA-7 is best applied by sprayer and followed immediately by back-brushing to work the finish into the wood surface and promote the most even coverage and color. Small sections will help maintaining a wet edge to avoid lap marks. Stop your application lines at natural break points such as corners, window and door edges, butt joints.

If wood has been media blasted, the use of Prelude™ Clear Wood Primer prevents over-absorption of the stain resulting in uneven and darker than expected colors.

#### LIMITED WARRANTY

Perma-Chink Systems, Inc. warrants and represents that Perma-Chink Log Home Products will conform to the description and specifications previously set forth and be free from defects in material and workmanship when shipped to the buyer. EXCEPT WHEN HEREIN EXPRESSLY STATED, THERE ARE NO WARRANTIES, EXPRESSED OR IMPLIED, BY OPERATION OF LAW OR OTHERWISE, APPLICABLE TO THIS PRODUCT. PERMA-CHINK SYSTEMS EXPRESSLY DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

**Do not apply to hot surfaces or in direct sunlight.**

**Vertical surfaces** – (walls, posts, etc) After LIFELINE™ ULTRA-7 has dried **4-6 hours**, one coat of LIFELINE Advance™ clear topcoat should be applied to add depth and extend the life of the finish system. LIFELINE Advance™ provides better appearance and adds an extra layer of protection against water, UV and contaminants, as well as making the surface much easier to keep clean.

**Horizontal surfaces** – (decks, handrails, etc.) One coat of LIFELINE™ ULTRA-7 is all that should be applied to horizontal surfaces. **DO NOT APPLY LIFELINE ADVANCE™ TO DECKS, HANDRAILS AND OTHER HORIZONTAL SURFACES.**

### STEP #4: CLEANUP

Clean area and equipment immediately with warm, soapy water. For sprayers and other commercial equipment, follow the manufacturer's directions. For removing LIFELINE™ ULTRA-7 that has dried, soften with alcohol or mineral spirits and then clean with warm water. Please do not pollute our environment. Dispose of containers and unused material in accordance with local, state and federal regulations.

### STEP #5: MAINTENANCE

Wood checking, cracking and shrinkage may expose unprotected wood. Apply periodic maintenance coats as needed. Additional maintenance coats of LIFELINE™ ULTRA-7 or LIFELINE Advance™ may be applied directly over the existing LIFELINE™ finish as needed. Apply in thin coats to avoid film build-up. Clean the surface with Log Wash™ before any maintenance application.

### STEP #6: STORAGE

Store LIFELINE™ ULTRA-7 out of direct sunlight and do not allow product to freeze.

#### CAUTION: PLEASE READ CAREFULLY!

DO NOT TAKE INTERNALLY. IF SWALLOWED, DRINK MILK. DO NOT INDUCE VOMITING. CONSULT A PHYSICIAN IMMEDIATELY.

KEEP OUT OF REACH OF CHILDREN.

KEEP CONTAINER TIGHTLY SEALED AFTER EACH USE.

USE ONLY IN WELL VENTILATED AREA. DO NOT INHALE VAPORS.

USE CAUTION WHEN APPLYING AROUND LAWNS AND SHRUBBERY.



1-800-548-3554

[www.permachink.com](http://www.permachink.com)